

Ⓛ Aufbauanleitung

Ⓛ Notice de montage

Ⓛ Handleiding voor de montage

Ⓛ Montážní návod

Ⓛ Szerelési útmutató

Ⓛ Montaj talimatları

Ⓛ Assembly instruction

Ⓛ Istruzione di montaggio







Ⓛ Instrukcja montażu

Ⓛ Navod na montaž

Ⓛ Instrucțiuni de montaj

Ⓛ Инструкция по монтажу

36-1006-39-07M






Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба



Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тиро • Тип




A	006181-39	x2
B	006281-39	x2
C	006382-39	x2
D	149410-32	x2
E	006580-52	x4
F	006381-39	x2



6





13



14


1-000001=



17




18




19

		mm	
6	1-000013-00	8x40	x12
13	1-000117-07	D=28	x8
14	1-000091-07	3x20	x16
17	1-000046-07	L34	x8
18	1-000048-07	15x12	x8
19	1-000057-57	3,5x40	x8


1.



2.



3.



4.

