

Ⓛ Aufbauanleitung

Ⓛ Notice de montage

Ⓛ Handleiding voor de montage

Ⓛ Montážní návod

Ⓛ Szerelési útmutató

Ⓛ Montaj talimatları

Ⓛ Assembly instruction

Ⓛ Istruzione di montaggio







Ⓛ Instrukcja montażu

Ⓛ Navod na montaž

Ⓛ Instrucțiuni de montaj

Ⓛ Инструкция по монтажу

# 36-1006-00-07M






# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба





Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тиро • Тип



<b>A</b>	006181-00	x2
<b>B</b>	006281-00	x2
<b>C</b>	006382-00	x2
<b>D</b>	149410-00	x2
<b>E</b>	006580-52	x4
<b>F</b>	006381-00	x2





1-000001=



6

13

14




17

18


19

		mm	
<b>6</b>	1-000013-00	8x40	x12
<b>13</b>	1-000117-07	D=28	x8
<b>14</b>	1-000091-07	3x20	x16
<b>17</b>	1-000046-07	L34	x8
<b>18</b>	1-000048-07	15x12	x8
<b>19</b>	1-000057-57	3,5x40	x8


1.



2.



3.



4.

