

Ⓛ Aufbauanleitung

Ⓛ Notice de montage

Ⓛ Handleiding voor de montage

Ⓛ Montážní návod

Ⓛ Szerelési útmutató

Ⓛ Montaj talimatları

Ⓛ Assembly instruction

Ⓛ Istruzione di montaggio







Ⓛ Instrukcja montażu

Ⓛ Navod na montaž

Ⓛ Instrucțiuni de montaj

Ⓛ Инструкция по монтажу

# 36-1006-42-000






# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба



Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тиро • Тип




|          |           |    |
|----------|-----------|----|
| <b>A</b> | 006100-42 | x2 |
| <b>B</b> | 006210-42 | x2 |
| <b>C</b> | 149312-42 | x2 |
| <b>D</b> | 149410-32 | x2 |
| <b>E</b> | 006510-52 | x4 |
| <b>F</b> | 149311-42 | x2 |



6





13



14


1-000001=



17




18




19

|    |             | mm     |     |
|----|-------------|--------|-----|
| 6  | 1-000013-00 | 8x40   | x12 |
| 13 | 1-000117-07 | D=28   | x8  |
| 14 | 1-000091-07 | 3x16   | x16 |
| 17 | 1-000046-07 | L34    | x8  |
| 18 | 1-000048-07 | 15x12  | x8  |
| 19 | 1-000057-57 | 3,5x40 | x8  |


1.



2.



3.



4.

