

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio





Ⓟ Instrukcja montażu

Ⓒ Navod na montaž

Ⓡ Instrucțiuni de montaj

Ⓡ Инструкция по монтажу

# 36-1027-46-000





# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название



Nr. • No. • No. • N° • Č • Sz • Номер

Typ • Type • Type • Tip • Tipus • Druh • Тіро • Тип



## Detail specification

A.i. Nr.	Article Nr.	pcs
H2	112510-46	x1
G3	112222-46	x2
G	112221-46	x2
E	112111-46	x2
F	112112-46	x2




## Fitting specification


A.i. Nr.	Article Nr.	Dimentions	pcs
①	1-000013-00	8x40	x8
②	1-000172-07	7x70	x8
③	1-000015-07	z=4	x1
④	1-000168-07	4.5x80	x4

0  
10  
20  
30  
40  
50  
60  
70  
80  
90  
100  
110  
120  
130  
140  
150  
160  
170  
18


①



②




③




④




1-000001=



1.



2.



3.

