





- Ⓓ Aufbauanleitung  
Ⓕ Notice de montage  
Ⓔ Handleiding voor de montage  
Ⓒ Montážní návod  
Ⓗ Szerelési útmutató  
Ⓓ Montaj talimatları
- Ⓖ Assembly instruction  
Ⓙ Istruzioni di montaggio  
Ⓟ Instrukcja montażu  
Ⓚ Navod na montaž  
Ⓡ Instrucțiuni de montaj  
Ⓡ Инструкция по монтажу

# 36-1046-32-00D





# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тиро • Тип




0  
10  
20  
30  
40  
50  
60  
70  
80  
90  
100  
110  
120  
130  
140  
150  
160  
170  
180




<b>F</b>	007046-32	x1
<b>G</b>	007414-32	x2




21




23



24



1-000001=



		mm	
21	1-000020-07	3,5x25	x3
23	1-000093-07	3,5x15	x3
24	1-000018-07	48x40x2,5	x1

# 5.

