

Ⓛ Aufbauanleitung

Ⓛ Notice de montage

Ⓛ Handleiding voor de montage

Ⓛ Montážní návod

Ⓛ Szerelési útmutató

Ⓛ Montaj talimatları

Ⓛ Assembly instruction

Ⓛ Istruzioni di montaggio







Ⓛ Instrukcja montażu

Ⓛ Navod na montaž

Ⓛ Instrucțiuni de montaj

Ⓛ Инструкция по монтажу

# 36-1053-82-000





# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба




Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тіро • Тип



<b>A</b>	013105-82	x1
<b>B</b>	013100-32	x1
<b>C</b>	013101-32	x2
<b>D</b>	004810-00	x13




1-000001=



		mm	
①	1-000095-07	M6x16/6	x4
②	1-000111-07	M6x60	x4
③	1-000012-07	3x30	x26
④	1-000013-00	8x40	x4
⑤	1-000015-07	Z4	x1
⑥	1-000091-07	3x16	x8
⑦	1-000090-07	D40	x4
⑧	1-000113-82	67x67	x1

# 1.



# 2.

