

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Handleiding voor de montage

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzione di montaggio



Ⓟ Instrukcja montażu

Ⓚ Navod na montaž

Ⓡ Instrucțiuni de montaj

Ⓡ Инструкция по монтажу

# 36-2501-LB-07M






Service • Assistenza • Dienstverlening • Serwis  
 Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
 Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер

Typ • Type • Tip • Tipus • Druh • Типо • Тип



1	x1
2	x1
3	x1



a



b

		mm	
a	1-000146-07	2x25	x6
b	1-000147-07	2x25	x6
c	1-000151-75	3,75x1400	x1
d	1-000150-75	3,75x600	x2




c




d


1-000001=




1.



2.



3.



4.

