

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio





Ⓟ Instrukcja montażu

Ⓢ Navod na montaž

Ⓡ Instrucțiuni de montaj

Ⓡ Инструкция по монтажу

36-4248-82-000






Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба



Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название

Nr. Nr. • No. • N° • Č • Sz • Номер

Typ • Тип • Type • Tip • Tipus • Druh • Тиро • Тип




①	132224-82	x1
②	132120-82	x1
③	132321-82	x1
④	132324-82	x1
⑤	132420-82	x2




Fitting specification


A.i. Nr.	Article Nr.	Dimintions	pcs
b	1-000013-00	8x40	x12
c	1-000057-07	3,5x40	x14
e	1-000174-07	4,5x15	x20
f	1-000035-07	3x15	x4
g	1-000173-07	38x30	x2
h	1-000185-07	D=40	x4
j	1-000014-57	8/13x6,2	x8
s	1-000245-00	L=225	x1
t	1-000012-07	3x30	x4
u	1-000015-07	Z4	x1




1.



3.



2.



4.

